





Build a
Food Mixer





CAUTION - ELECTRIC TOY: ⚠
Not recommended for children
under 8 years of age.
FOR INDOOR USE ONLY.




K'NEX print

11	U	4	⚙	2	⚙
6	H	5	⚙	1	⚙
2	H	30	⚙	4	⚙
13	⚙	24	—	1	⚙
2	⚙	16	—	1	⚙
8	⚙	5	—	1	⚙
12	⚙	8	—	1	⚙


WARNING: Keep hands, face, hair,
clothing away from all moving parts.




9




1 - 8



10



11



1 - 11